








# 보령문화예술회관 무대조명 상부 배치도



# 보령문화예술회관 무대조명 하부 배치도

DMX. 26						DMX. 26	
RD26						RD26	
258	257	256	255	254	253		
252	251	250	249	248	247		
<b>NO.3 GALLERY (L)</b>							

<b>NO.4 FLOOR POCKET (L)</b>			

<b>NO.4 FLOOR POCKET (R)</b>			

DMX. 25						DMX. 25	
RD25						RD25	
246	245	244	243	242	241		
240	239	238	237	236	235		
<b>NO.3 GALLERY (R)</b>							

288	287
<b>NO.3 USRB D/L</b>	

DMX. 24						DMX. 24	
RD24						RD24	
234	233	232	231	230	229		
228	227	226	225	224	223		
<b>NO.2 GALLERY (L)</b>							

RD 36	RD 35	282	281
<b>NO.3 FLOOR POCKET (L)</b>			

RD 36	RD 35	282	281
<b>NO.3 FLOOR POCKET (R)</b>			

DMX. 23						DMX. 23	
RD23						RD23	
222	221	220	219	218	217		
216	215	214	213	212	211		
<b>NO.2 GALLERY (R)</b>							

286	285
<b>NO.2 USRB D/L</b>	

DMX. 22						DMX. 22	
RD22						RD22	
210	209	208	207	206	205		
204	203	202	201	200	199		
<b>NO.1 GALLERY (L)</b>							

RD 34	280	279	278
<b>NO.2 FLOOR POCKET (L)</b>			

RD 34	280	279	278
<b>NO.2 FLOOR POCKET (R)</b>			

DMX. 21						DMX. 21	
RD21						RD21	
198	197	196	195	194	193		
192	191	190	189	188	187		
<b>NO.1 GALLERY (R)</b>							

284	283
<b>NO.1 USRB D/L</b>	

DMX 30	DMX 30	DMX 29	DMX 29
RD 30	RD 30	RD 29	RD 29
274	273	272	271
270	269	268	267
<b>STAGE WALL MOUNT.L</b>			

RD 33	277	276	275
<b>NO.1 FLOOR POCKET (L)</b>			

RD 33	277	276	275
<b>NO.1 FLOOR POCKET (R)</b>			

R40	R39	R38	R37
<b>HOUSE LIGHT</b>			

DMX 28	DMX 28	DMX 27	DMX 27
RD 28	RD 28	RD 27	RD 27
266	265	264	263
262	261	260	259
<b>STAGE WALL MOUNT.R</b>			

185	186	185	186	185	186
<b>FRONT SIDE LIGHT (L)</b>					

RD32	RD31
<b>ORCHESTAR FLOOR POCKET (L)</b>	

RD32	RD31
<b>ORCHESTAR FLOOR POCKET (R)</b>	

183	184	183	184	183	184
<b>FRONT SIDE LIGHT (R)</b>					